

Multimedia Equipment

To be used for rooms: AS228, AS229, AS304, AS305, AS373, LC202, French Lab, FA224, FC2014, Rec Plex

To use the Data Projector with the computer and/or the DVD/VCR, here are the instructions:

- Make sure the Data Projector power switch, located on the wall, is **ON**.
- Power up the Data Projector with the remote supplied (This works best with the fluorescent ceiling lights **OFF**, as the lights emit waves that interfere with the remote).
- If you are **ONLY** using the computer, simply turn it on, the data projector will auto detect it. If you have sound with your computer presentation, turn the Power Amp **ON** (Top component in the AV Rack). Turn the **Input Selector** until **AUX** appears and then adjust the volume.
- If you are **ONLY** using the DVD/VCR, turn it on and then use the remote to change the source from the computer to the DVD/VCR (Use the Computer and Video buttons on the remote). Next, turn the Power Amp **ON**, turn the **Input Selector** to **CD** and adjust the volume.
- If you are using **BOTH** the computer and the DVD/VCR, you will have to make sure both units are on. You will then have to use the remote to switch between the computer and DVD/VCR (Use the source button on the remote). Next, turn the Power Amp **ON**, turn the **Input Selector** to **CD** and adjust the volume.

If you have any problems or questions, please feel free to contact the Help Desk at 639-2049 or by e-mail: avdesk@swgc.mun.ca.

